



105 Bonnie Drive
Butler, PA 16002
724-283-4681
724-283-5939 (fax)
www.bwieagle.com

PRODUCT INFORMATION BULLETIN

AIR-EAGLE® XLT 900 MHz RF Transmitter MODEL 441U-HH-9

DESCRIPTION

The AIR-EAGLE XLT TX is a handheld rechargeable** R.F. transmitter capable of sending up to 16 unique digital commands to an Air-Eagle XLT Receiver located up to 2500 feet away. Any number of transmitters and receivers can be combined to create a medium range radio frequency system that operates hazardous or hard-to-reach equipment from safe, convenient locations. Seven user-programmable frequencies allow multiple systems to operate simultaneously in the same area without interference. This transmitter will automatically go into "sleep" mode when no buttons are being depressed on the unit to dramatically extend battery life.

INITIAL SET-UP

This transmitter comes ready to operate and factory programmed to Frequency #1. No setup is necessary unless you wish to change frequency.

For example, if you are setting up this transmitter to use with an existing system that is operating on Frequency #1, no change in this setting is necessary. However, if you wish to operate this unit with a receiver on another network, follow the programming procedure on the next page to change the frequency setting appropriately. Charging of the battery can be done by plugging in a micro USB connector into the side port. The LED will blink RED while charging and blink GREEN when fully charged.

GENERAL OPERATION

This transmitter sends up to 16 independent commands. Each button sends an RF Code for that channel. Button 1 transmits channel 1 commands, button 2 transmits channel 2 commands etc. To send commands 9 thru 16, the P/Shift button must be used. As noted under CONTROLS & INDICATORS, the P/Shift button serves three purposes. As the "P" button, it allows you to program the transmitter to operate on a different frequency and/or digital address. As the "Shift" button, it allows you to send commands 9 thru 16 to the receiver.

To use as the "P" button, you must press and hold the button to enter programming mode. (See FREQUENCY & ADDRESS PROGRAMMING sections for more details).

To use as the "Shift" button, press the P/Shift button momentarily. The TX LED will begin to flash rapidly indicating you're in the Shift mode. While in shift mode pressing buttons 1 thru 8 transmit the higher numbered code for that button. The transmitter will stay in the Shift mode as long as buttons are being depressed within 10 seconds of one another. During this time, the TX LED gives visual confirmation that you're in Shift mode by continuously flashing GREEN/RED rapidly. After 10 seconds has elapsed with no buttons depressed, the transmitter will revert back to standard mode and the TX LED will extinguish. If, while in Shift mode, you wish to transmit a button 1 thru 8 command and don't want to wait for the Shift mode to time out, you can simply press the P/Shift button momentarily to revert back to the standard mode.



CONTROLS & INDICATORS

TX LED	LED illuminates "RED" continuously while button is depressed and unit is transmitting. When this LED blinks during a transmission, the battery needs to be recharged.
Keypad Pushbuttons 1 thru 8	Transmit CH.1 thru 8 individual button RF codes to the receiver
Pushbutton P/Shift	The P/Shift button performs three functions: 1. If button is depressed momentarily and another button is then pressed within 10 seconds, the higher code for that button is transmitted. This allows for transmission of pushbutton codes 9 thru 16. 2. If button is depressed for longer than 5 seconds, the transmitter will enter "programming" mode. See PROGRAMMING section. 3. See "Battery Charge Status" for using P/shift to see battery level.
Keypad Pushbuttons 9 thru 16	Transmit CH. 9 thru 16 individual button RF codes to the receiver

AIR-EAGLE® XLT

900 MHz RF Transmitter

MODEL 441U-HH-9

APPROVALS

United States (FCC)	MCQ-XB900HP
Canada (IC)	1846A-XB900HP

FREQUENCY PROGRAMMING

Please read through these instructions completely before beginning programming procedure!

At any time, you can check the current frequency setting by depressing the P/Shift button, for approximately 5 seconds, until the TX LED is illuminated "RED". Then release the P/Shift button and watch until the TX LED begins to blink. The TX LED will blink "RED" one, two, three or four times for Frequencies 1 thru 4, or will blink "GREEN" one, two, three or four times for Frequencies 5 thru 8 accordingly. See table below for clarification.

LED Flashes:	Indicates Unit is Operating On:
RED – one time	Frequency 1
RED – two times	Frequency 2
RED – three times	Frequency 3
RED – four times	Frequency 4
GREEN – one time	Frequency 5
GREEN – two times	Frequency 6
GREEN – three times	Frequency 7

To change the FREQUENCY setting, follow these steps:

To select from Frequencies 1 thru 8:

- Depress the P/Shift button until the TX LED is illuminated "RED". (Approximately 5 seconds)
- Release the P/Shift button, then while the TX LED is still illuminated "RED", depress button #1 to select "Frequency 1" or button #2 to select "Frequency 2" etc. If the transmit LED goes out before you have selected a network, no settings will have changed, **and** the LED will blink corresponding to the frequency that the TX is currently set to. You must then begin again at step 1 if you wish to change the current setting.
- The TX LED will blink to confirm that your frequency selection has been accepted, and then will go out. For instance, if you have selected Frequency #1, the TX LED will blink "RED" once to confirm. If you have selected Frequency #6, the TX LED blinks "GREEN" two times to confirm.

You may repeat the above procedure if you wish to change the frequency at any time. See note* in SPECIFICATIONS.

SPECIFICATIONS

Keypad	Durable Sealed Microswitch Keypad – Eliminates Dust, Dirt and Moisture Failures
Enclosure	ASA/Polycarb Blend – IP54 – <i>Not Water Proof!</i>
Power Requirements	Charging cable (included) Micro USB connector to USB A type – 5 volts 1 amp
Battery Type	Internal Sealed Lithium Rechargeable. Capacity 3.7V 2000mAh
Battery Life (Active Usage)	Up to 2 months
Battery Life (Sleep Mode)	Up to 6 months
Battery Recharge Time	Approximately 3 to 4 Hours
Transmit Frequency	900 MHz Spread Spectrum
RF Output Power	250 mW
Transmit Channels	Seven Independent Network Frequencies
Transmit Range	Up to 2500 Feet (Line of Sight)
<small>Note: Range figures are estimates, based on free-air terrain with limited sources of interference. Actual range will vary based on transmitting power, orientation of transmitter and receiver, height of transmitting antenna, height of receiving antenna, weather conditions, interference sources in the area, and terrain between receiver and transmitter, including, but not limited to, indoor and outdoor structures such as walls, metal objects, trees, buildings, hills, and mountains</small>	
Operating Temperature	-40° F to +185° F

LIMITED WARRANTY STATEMENT

BWI Eagle Inc. warrants the Air-Eagle Remote Control System, if properly used and installed, will be free from defects in material and workmanship for a period of 1 year after date of purchase. Said warranty to include the repair or replacement of defective equipment. This warranty does not cover damage due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, misuse, neglect, alteration, repair, improper installation, or improper testing. This warranty also does not cover water damage to any handheld transmitter. This limited warranty, and any implied warranties that may exist under state law, apply only to the original purchaser of the equipment, and last only for as long as such purchaser continues to own the equipment. This warranty replaces all other warranties, express or implied including, but not limited to, the implied warranties or merchantability and fitness for a particular purpose. BWI Eagle makes no express warranties beyond those stated here. BWI disclaims without limitation, implied warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not allow the exclusion of implied warranties so this limitation may not apply to you. To obtain warranty service, contact BWI Eagle for a return material authorization. When returning equipment to BWI Eagle, the customer assumes the risk of damage or loss during shipping and is responsible for the shipping costs incurred.

DOCUMENT REV. DATE: 11/3/2020 / PRODUCT REV.1



105 Bonnie Drive
Butler, PA 16002
(724) 283-4681
Fax (724) 283-5939
www.bwieagle.com